

The AT&T VoiceMail User Guide



Keep this guide for future reference

LOOK INSIDE FOR:

- > Your access number and password
- > How to get started
- > Basic and advanced features
- > A handy wallet reference card

CONTENTS

Welcome	1
Getting Started	2
VoiceMail Service Basics	3
Advanced Features	4
VoiceMail Plus	8
Terms and Conditions	12

Your VoiceMail Access Number: 1 888 288-8893

Your Temporary Password: 1 1 1 1 1 1

Playback Controls

While listening to your messages

1	2	3	
Rewind/Replay Message	Reply	Delete	
4	5	6	
Save as New	Header Information	Slowdown/Speed Up Playback	
7	8	9	
Rewind 8 Seconds	Increase/ Decrease Volume	Press Once: Fast Forward 8 Seconds	Press Twice: End of Message
*	0	#	
Exit	Help	Press Once: Save	Press Twice: Get Saved Messages

3	1	4	1
Change Greeting		Change Password	

Access number
1 888 288-8893



**Punch out this handy wallet card
for a quick reference guide.**

AT&T VoiceMail

To listen to your messages, dial
1 888 288-8893.

- When *calling from home*, if prompted, enter your password followed by **#**.
- If *you are not calling from home*, you will be prompted to enter your 10-digit phone number followed by your password — just follow the system prompts.
- After playback, please follow the prompts.

Questions?

**Call 1 800 288-2747
from any phone.
localhelp.att.com**

